## **MOUNTING PROCEDURE**

KIT LICENCE PLATE **DUCATI MONSTER 696** 

**DN7104-BN** 

## WWW.BARRACUDAMOTO.COM

motorbike

lock

## KIT

- X1. SPECIFIC LICENCE PLATE
- X1. UNDERTAIL
- X1. SPECIFIC BRACKET LED TAIL LIGHT
- X2. GRAFTS
- X2. SHIM 20 MM
- X2. ROUND HEAD SCREWS 6X40 MM
- X2. WASHERS LARGE Ø6
- X2. ROUND HEAD SCREWS 5X16 MM X2. ROUND HEAD SCREWS 8X20 MM
- X2. WASHERS LARGE Ø 8
- X2. LOCKING NUTS Ø 8 MM X2. LOCKING NUTS Ø 6 MM



Remove the rubber thickness



Install the tail light using the bracket and mount it under the Barracuda saddle specific frame using the appropriate special connection and the supplied screws.

Screw 6x40 REMOVE THE SADDLE AND DISASSEMBLE THE ORIGINAL LICENCE PLATE, DISCONNECT ALL THE CONNECTORS ABOUT THE ELECTRONIC CONNECTION. GET OFF THE CYLINDER OF THE LOCK AND FIXS IT ON THE BARRACUDA UNDERTAIL. REMOVE TWO RUBBER SHIMS THAT ARE IN THE HIGHER PART OF REAR FRAME OF MOTORBIKE LIKE DE-SCRIBED ABOVE; FIX THE TAIL LIGHT ON BARRACUDA STEEL BRACKET AND FIXS IT TO THE FRAME OF MOTORBIKE USING THE SPECIAL GRAFTS LIKE DESCRIBED INTO THE SCHEME.

APPLY THE BARRACUDA UNDERTAIL FIXING IT TO THE CHASSIS OF MOTORBIKE AND TO THE STEEL BRACKET TOO, USING THE SCREWS ABOVE.

Screw 8x20 Large washer Ø 8

> Special Insert

> > Steel Bracket

LED Tail light

Screw 5x16

APPLY AGAIN THE SADDLE.

Nut Ø 6

Washer

Thickness 20mm

Ø 6

WE ADVICE AN INCLINATION NOT EXCEEDING TO 30° TO AVOID SANCTIONS AND POSSIBLE DAMAGES.